




Model: HC-AB00-QS

-Coupling





-Return Loss



Model: HC-AB00-QS

-Isolation



-Phase

