


Model: PD-R000-2S

-Insertion Loss



-Return Loss



Model: PD-R000-2S

-Isolation



-Phase Error

