



Model: PS-L000-2S

-Insertion Loss



-VSWR



Model: PS-L000-2S

-Isolation



-Phase Balance

