


Model: PS-3000-4X

-Insertion Loss



-Return Loss



Model: PS-3000-4X

-Isolation



-Phase Error

