




Model: PS-D000-4S

-Insertion Loss




-Return Loss



Model: PS-D000-4S

-Isolation



-Phase Error

