



Model: SR-U000-TS

-Insertion Loss



-Return Loss



Model: SR-U000-TS

-Isolation

